
Product Code: CHEETO-ERGO

Product Name: Cheeto Ergo Task Chair





## **User Information**

Back height adjustable: Turn knob to adjust back height.

Height adjustable: Lift lever A.

Back tilt / lock: Lever B up / down.

Seat tilt / lock: Lever C up / down.

## **CHAIR CARE**

\*Clean regularly.

\*Use leather cleaner where leather is applicable.

\*Use wet towel where is applicable.

\*Test on concealed area before proceeding.

## WARNING

- \*Do not use this chair unless all bolts/knob are tightened and this chair is assembled firmly and properly.
- \*This chair is for one person to sit on. Do not stand on the chair.
- \*Do not touch mechanism except lever handle/knob when people is sitting in.
- \*Only trained personel replace or repair cylinder.
- \*Failure to follow these warnings could result in serious injury.

